


AVAILABLE SIZES: THE FOLLOWING ARE WEARER BODY MEASUREMENTS

	Height	Inside Leg
Short	164 - 172cm / 5'5" - 5'8"	73cm / 29"
Regular	172 - 180cm / 5'8" - 5'11"	78cm / 31"
Tall	180 - 188cm / 5'11" - 6'2"	83cm / 33"
X-Tall	188 - 196cm / 6'2" - 6'5"	88cm / 35"

Tunic Size	Chest	Trouser Size	Waist
X-Small	88-96cm / 34-37"	X-Small	74-82cm / 29-32"
Small	96-104cm / 37-40"	Small	82-90cm / 32-35"
Medium	104-112cm / 40-43"	Medium	90-98cm / 35-38"
Large	112-120cm / 43-46"	Large	98-106cm / 38-41"
X-Large	120-128cm / 46-50"	X-Large	106-114cm / 41-45"
2X-Large	128-136cm / 50-53"	2X-Large	114-122cm / 45-48"
3X-Large	136-144cm / 53-56"	3X-Large	122-130cm / 48-51"
4X-Large	144-152cm / 56-58"	4X-Large	130-138cm / 51-54"



MEASURING GUIDE

Measurements must be taken wearing clothing usually worn underneath PPE garments. The tape measure should be loose and not pulled too tight.

- Height - with bare feet together measure from the top of the head to the floor
- Chest/Bust - measure under the arms at the fullest part around the chest horizontally with arms by your side
- Waist - measure around the natural waistline at the fullest part
- Inside leg - in bare feet take the measurement from the top of the inside leg and measure down the insideleg to the floor

Once measurements are taken compare them to the fit guide measurement tables to find your Jacket and Trousers size.

If your chest and waist fall on the size break, choose the smaller size.

If your height and inside leg measurements fall into different length categories, then choose the Jacket length based on the height measurement and the trouser length based on the inside leg measurement.

Example for Male wearer:

Height measurement is 176cm = Regular length

Chest measurement of 118cm = size Large category

Waist measurement of 97cm = size Medium category

Inside leg measurement of 83cm = Tall length

This wearer would choose the following sizes:

Tunic: Large/Regular and Trousers: Medium/Tall